

# Courtyard "CRATE"

## Installation Guide

**COURTYARD**  
BY MARRIOTT®

### Checklist (Items Included)

- CRATE Graphic
- Metal Studs/Pins
- Paper Mounting Template

### Tools Required (Not included)

- Painter's Tape or Straight Pins
- Cordless Drill with 1/4" Bit
- Wall Punch (optional)
- Silicone Adhesive

### Installation Instructions:

1. Install moss on wall before installing the "CRATE" letters, keeping in mind that the letters will need to be installed in the center of the moss wall.
2. Securely screw the studs/pins into the back of the letters. (figure 1)
3. Decide where the sign should go, centering on the wall. Pin up or tape the paper template on the moss wall, being careful to not damage the moss wall. You will want this sign centered vertically and horizontally. *Optional Step: Prior to hanging the template, punch out the holes in the paper template (this will help since the wall isn't flat).*
4. Using a drill with a 1/4" bit, drill the holes, being sure to hold the drill as straight as possible. *Optional Step: Prior to drilling, use a wall punch to punch through the holes of the template and into the wall to mark where you should drill.* (figure 2)
5. Carefully remove the paper template and dry-fit the letters to make sure they fit and are straight, then remove. Make adjustments if required to the drill holes.
6. From there, apply a small drop of silicone adhesive into each hole you drilled. (figure 3)
7. Insert each letter into the holes you drilled. Gently press each letter down into the moss, making sure they are all the same depth.



Figure 1



Figure 2



Figure 3

### Installation Questions?

Call our customer service team at  
**888.273.8726**



MOSS SHOULD BE PLACED THOUGHTFULLY WITH  
THE CRATE LETTERS IN THE CENTER